



\*) If button is pressed briefly the following pause is 3 seconds. If the button is pressed and held for a longer period the pause is 10 seconds.

**Battery voltage:**  
If the battery voltage gets below approx 7 volt, the device will show "Low battery" in the display and beep continuously.

**Max time:**  
The speed timer will timeout after 999.999 seconds regardless of the number of shots fired. If all 99 shots have been fired it will stop immediately after the last shot.

**Shots recorded:**  
The speed timer records the time for all of the five first shots and the last shot fired.

**Interrupts:**  
If the button is pressed during action, the speed timer will stop and return to the previous mode

**Sounds signals in speed timer mode:**  
A short single beep indicates "Go"  
A long single beep indicates "Stop" due to the shooting is ended or interrupted by the user

**Sounds signals in sport shooting mode:**  
A double beep indicates "Started"  
A short single beep indicates "Go"  
A long single beep indicates "Stop" due to the shooting is ended or interrupted by the user