

*1 If button is pressed briefly the following pause is 3 seconds. If the button is pressed and holded for a longer periode the pause is 10 seconds.

Battery Voltage:
If the battery voltage gets below approx 7 volt, the device will show "Low battery" in the display and beep continously.

Max time:
The speed timer will timeout after 999,999 seconds regardless of the number of shots fired. If all 99 shots have been fired it will stop immediately after the last shot.

Shots recorded:
The speed timer records the time for all of the five first shots and the last shot fired.

Interrupt:
If the button is pressed during action, the speed timer will stop and return to the previous mode

Sounds signals in speed timer mode:
A short single beep indicates "Go"
A long single beep indicates "Stop" due to the shooting is ended or interrupted by the user

Sounds signals in sport shooting mode:
A double beep indicates "Started"
A short single beep indicates "Go"
A long single beep indicates "Stop" due to the shooting