

IR datalink menu selected, ready to receive IR data




No IR data received,  
timeout after 10 sec.



IR data  
not valid




IR data valid




Press select button  
to continue,  
data not saved

Data  
saved

Operation mode →



Reset menu selected,  
reset starts immediately,  
power led flashes slowly 3 times



Operation mode

Firmware menu selected,  
signal led flashes quickly  
a number of times equal  
to the firmware version

